

Oxivir® AHP® 5

Disinfectant Cleaner



One-step disinfectant cleaner based on proprietary accelerated hydrogen peroxide (AHP®) technology to deliver fast and effective cleaning, disinfecting and deodorizing performance in one easy step.

Broad Spectrum Activity

- ▶ Highly effective against a wide variety of pathogenic microorganisms
- ▶ Kills MRSA, VRE and Norovirus
- ▶ Virucidal and bactericidal
- ▶ Meets bloodborne pathogen standards for blood and body fluid clean-up
- ▶ Non-food contact sanitizer in 30 seconds
- ▶ Hospital-grade disinfectant

Cost-Effective

- ▶ Concentrate delivers economical performance
- ▶ At 1:16 dilution, disinfects in five minutes

Designed For

- ▶ Health Care
 - ▶ Education
 - ▶ Lodging
-



Use Overview

Oxivir® AHP® 5 Disinfectant Cleaner is a one-step disinfectant cleaner based on proprietary accelerated hydrogen peroxide (AHP®) technology to deliver fast and effective cleaning performance. At a 1:16 dilution, it disinfects in five minutes. Virucidal and bactericidal. This product also provides broad spectrum sanitizing on hard surfaces in 30 seconds. Concentrate delivers economical performance. Meets bloodborne pathogen standards for decontaminating blood and body fluids.



- ▶ Heavily soiled surfaces require cleaning prior to disinfection.
- ▶ Dilute 1:16.
- ▶ Apply to surface with cloth or disposable wipe.
- ▶ Ensure surface remains wet for five minutes at 20° C.
- ▶ Wipe dry or rinse.

Product Specifications

| Description | |
|-------------------------|--|
| Color/Form | Colorless, liquid |
| DIN No. | 02287382 |
| Flash Point | > 200° F (> 93.4° C) |
| pH | 0.7 (Concentrate) 1.0 (Use Dilution 1:16) |
| Scent | Characteristic |
| Shelf Life | 2 years |
| Solubility | Complete |
| Specific Gravity | 1.069 |

Hazard Rating

| HMIS | | NFPA |
|------|--------------|------|
| 3 | Health | 3 |
| 0 | Flammability | 0 |
| 0 | Reactivity | 0 |

4=Very High; 3=High; 2=Moderate; 1=Slight; 0=Insignificant.

Available Items

| Product Code | Description/Package Size | Dilution |
|--------------|---------------------------------|-------------------|
| 4277314 | 2 x 1.5 L / 1.59 Qt. RTD® Units | 1:16, 1:64, 1:128 |

Safety Reminder

Please make sure your employees read and understand the product label and Material Safety Data Sheet before using this product. The label contains directions for use, and both the label and MSDS contain hazard warnings, precautionary statements and first aid procedures. MSDS are available on-line at www.diversey.com or by calling 888 352 2249.

Accelerated Hydrogen Peroxide[™] and AHP logos are trademarks owned by Virox Technologies used under license.

For additional information, please contact us at +1 800 558 2332 or at www.diversey.com
© 2012 Diversey, Inc., 8310 16th Street, Sturtevant, WI 53177-1964. All Rights Reserved. SPC741 (12/067)

Diversey
for a cleaner, healthier future[™]